




FLOW CHART 3 STEP TOTAL RUST ERADICATION



*This Flow Chart is meant to be a general application guideline only and does not cover every application or environmental situation. If you have remaining questions or concerns, please call us for technical assistance. 1800 80 90 36.